08. SETTINGS FOR THE PART PROGRAM

As indicated in Section 3, every program in SPRING has default settings for the current program and is dependent on the tooling of the machine. These settings are accessed by pressing the F2 key.

FI	LE	s١	/STE	м	HEL	Р				VINS	том м	ACHIN	IERY
сит	[F4]	1	RUN	то і	F5]		STOP [F6]		RUN TOP	[F7]	RUN	LINE C	-81
							RUNNING SPEE	D	[PAD-/+]	OR [O/P	:	6%	
	BLA	DE:	AY				P-INDE>			FILE:	VINST	ом∖јонм	I
CF2	1->	BLA	DE	D	EFAUL	_T	SET [+/-]	5	SPEED_C	HANGE			
o		ENAB	3LE/DI	ISAB	LE AXI	SES)						
		AUTOMATIC CUTTER											
1				B	BLZJ	=0:00	1						
2					AE 13	=0.00	BE2] =0.00						
_				B									
з													
4													

08.1 ENABLE/DISABLE AXES

To access the menu, press F2 on your keyboard and and press ENTER as the ENABLE/DISABLE AXISES option is the default selection. To exit, press the ESC key.



Use the SPACE BAR to enable/disable the highlighted axis. Press the ENTER key to exit and confirm the current settings.

08.2 AUTOMATIC CUTTER

To access the menu, press F2 on your keyboard and navigate with the $\mathbf{\nabla}$ arrow key. Press the ENTER key to confirm your selection. To exit, press the ESC key.

FI	LE ۵۱	/STE	EM HE	ELP						, t	JINS	TON 1	1ACHIN	ERY
сит	[F4]	RUN	TO [F5]		STOP	[F6]			RUN T	OP [F	7]	RUN	LINE CF	81
					RUNN	ING S	PEED	C F	PAD−∕	+] OR	[0/P]:	6%	
	BLADE:	AY			P-	INDE)				FI	LE:	VINST	гон√јони	
CF2	2]-> BLA	DE	DEFA	ULT	SE	T C+/	- 1	SP	EED_	_CHA	NGE			
o		AUT	O CUTTER	R SETUR										
1		1.	CUTTER: VALUE:	N/A 🛛	A ∎	в 🗖	c 🗖	D 🗖	E 🗖	F 🗖	G 🗖	н		
2		2.	HELPER:	N∠A⊠		в 🗆	сП	▫◻	Е 🗆	F 🗖	G 🗖	нП		
3			VALUE:											
4		3.	VALUE:	X:										
5		4.	QUILL:	RQ: 🗌										
6		_	VALUE:			_								
7		ъ.	TTORHUL											
8		6.	CUTTER	SPEED:	10									

Set the following values:

- 1) Select the axis with the mounted blade designated for the wire cutter.
- 2) Designate any additional axes to help with the wire cutting process.

3) The cutting speed.

Press ENTER to confirm the settings and exit. After setting the values for the auto cutter setup, perform a system reset.

The wire cutter function is executed by pressing the F4 key on your keyboard. The indicator at the top left hand area will change color (green background) and a confirmation window appears.



After confirming the command, the designated wire cutter blade will move to its zero (reset) position. The machine will feed 20 mm of wire (this is the default feed length) and the Quill will move into the cutting position. The slide with the mounted blade will move into the cut position and return to its previous position after the cut.

08.3 SLIDE SPEED

To access the menu, press F2 on your keyboard and navigate with the $\blacktriangleright \nabla$ arrow key. To confirm press the ENTER key or to exit press the ESC key.

			C F	23->	BL	ADE.	DEF	AULI		SET [+/	<u>-</u>	
			0				BLAD)E SPI	EED			
			_				FAUL	T FE	ED L	ENGTH		
			_									
FI	LE S	YSTE	M	HEL	Р					UINST	ron	MACHINERY
сит	[F4]	RUN	TO I	(F5)		STOP [F	6]	F	UN T	OP [F7]	RL	JN LINE [F8]
						RUNNING	SPEED	C P	AD−∕	+] OR [O∕P]		6%.
	BLADE:	AY				P-IND)E)			FILE:	VIN	STONKJOHN
CF2	J→ BL	ADE	D	EFAUL	. T	SET	+/-]	SP	EED.	_CHANGE		
0				AE 13	=0.0	00						
			8	BE21	DEF	AULT BLA	DE SPE	ED SE'	rup			
1			B									
2			в	AE 13	BL	ADE SPEE	D: 🧕		(0-	-15)		
з												-
4												
5												
6												

Enter a value between 0 and 15 for the speed of all blades. It is highly recommended to initially start with a low value until the operator becomes more familiar with the machine.

FAULT FEED LENGTH

To access the menu, press F2 on your keyboard and navigate with the $\triangleright \lor$ arrow key. To confirm press the ENTER key and to exit press the ESC key. When the probe sensor cannot touch the wire at the designated time interval during normal operations, the program will do a wire feed. This will help the operator to identify possible issues within the program.



When the probe sensor triggers a fault event, the machine move the slides to their corresponding zero (reset) positions and feeds wire designated by the Fault Feed Length. At this time, a GO command can be triggered to jump to another line of code within the program. For further details, refer to the section on probe sensor settings.

08.4 SET DEFAULT WIRE FEED/DETRACT LENGTH

To access the menu, press F2 on your keyboard and navigate with the $\triangleright \lor$ arrow key. To confirm press the ENTER key or to exit press the ESC key.

FI	LE	s١	/STE	M	HELP				UINST	ron Mach	INERY
сит	[F4]		RUN	то і	(F5)	STOP [F6]		RUN TOP	[F7]	RUN LINE	[F8]
						RUNNING SPE	ED	[PAD-/+]	OR [0∕P]	: 6	%
	BLAD	E:	AY			P-INDE>			FILE:	VINSTON	OHN
CF2	1-> I	BLA	DE	D	EFAULT	SET [+/-	1	SPEED_C	HANGE		
0				8	AE 13 0.	20.00mm 01 50.00mm					
1				B	BE23 =0.	0(100.00mm 350.00mm					
2				B	AE13 =0.	00 <mark> BLZ] =0.00</mark>					
3											
4											
5											
6											
7											
8											
	CFILE	:	SAVI	ED		CPOWER]: CTIMEJ:	SERV0 03/16) ON 5 11:52:21	[MODE]	: EDITIN T1=1 2	3 =1 3=1

Choose a value of 20/50/100/350 mm for the default feed length using the + and - keys. One common use for these keys (+/-) is during the initial wire straightening process.

08.5 SPEED DEFAULTS

To access the menu, press F2 on your keyboard and navigate with the $\triangleright \lor$ arrow key. To confirm press the ENTER key or to exit press the ESC key.

FI	LE S'	YSTEM	HELP		UINS	TON MACHINERY
сит	[F4]	RUN TO) [F5]	STOP [F6]	RUN TOP [F7]	RUN LINE (F8)
				RUNNING SPEED	[PAD-/+] OR [0/P	1: 6%
	BLADE:	AY		P-INDE>	FILE:	VINSTON-JOHN
CF2	21-> BLA	ADE I	DEFAULT	SET [+/-]	SPEED_CHANGE	
0			AC 13 0.	00	GROUP SPEED FEED SPEED ONLY	
1		B	B[2] ≑0.	00	BLADE SPEED ONLY RW SPEED	
2		в	AE13 =0.	00 B[2] =0.00	RQ SPEED	
з		-				
4						
5						
6						
7						
8						
	(FILE):	SAVED		CPOWERJ: S CTIMEJ: O	ERVO ON [MODE 3/16 11:52:21 [PIN]:]: EDITING : T1=1 2=1 3=1

08.6.1 GROUP SPEED



GROUP SPEED: Change the speed of all axes on the selected line of code. The operator can set a value between 0 and 15.

08.6.2 FEED SPEED ONLY



FEED SPEED ONLY: Change the wire speed on the selected line of code. The operator can set a value between 0 and 15.

08.6.3 BLADE SPEED ONLY

FI	LE S'	YSTEI	4	HELP				UINST	DN MACHINERY
сит	[F4]	RUN	то і	:F5)	STOP [F6]		RUN TOP I	(F7)	RUN LINE (F8)
					RUNNING SPE	ED	[PAD-∕+] (DR [O∕P]:	6%
	BLADE:	AY			P-INDE>			FILE:	VINSTON、JOHN
CF2	3-> BLA	DE	D	EFAULT	SET [+/-	1 S	PEED_CH	IANGE	
o				AE 13	.00				
1				BE23	ADE SPEED ONL	.Y			
2			UBAA.	AE 13 C	HANGE SPEED	8	(0-15)		
3			B						
4									
5									
6									
7									
8									
	(FILE):	SAVE	D		[POWER]: [TIME]:	SERV0 03/16) ON 5 11:57:44	[MODE]: [PIN]:	EDITING T1=1 2=1 3= <u>1</u>

BLADE SPEED ONLY: changes the speed of the slides on the selected row. The operator can set a value between 0 and 15.

ROTARY WIRE SPEED



ROTATION WIRE SPEED: change the speed of the wire rotation on the selected row. The operator can set a value between 0 and 15.