




MONITOR DISPLAY

There are two main display modes: EDITING and PRODUCTION MODE. They are used according to the type of operation in progress: To set up the production process or to mass produce the part.



(I) EDIT MODE:
MODE

(J) PRODUCTION



Commands and displays are grouped into two types:

- Independent of the operating mode.
 - o F1 Function: machine function settings and file settings.



- o Command bar for the execution of programs



- o Display current values and current file in use




- o Status Bar




- Dependent on the operating mode.


- o F2 bar:
 - In EDIT MODE, the highlighted bar indicates the function being set to the axis within the program. Multiple axes can be programmed within the same step.



- In PRODUCTION MODE, a set number of parts are produced with the production rate and other statistics.




- RPG CONTROL: It is only available during EDIT MODE for axis motion and speed control.




03.1 MAIN MENU BAR IN EDIT MODE

Functions and Settings in this manual are comprehensive of all programs for all new models VINSTON Machinery Ltd.


03.1.1 – F1 MAIN: MAIN FUNCTIONS FOR USE



Press F1 to access the main menu bar. To navigate through the main menu, move the arrow keys ◀ ▶ located on the keyboard. To exit the main menu bar, press ESC.

SAVE	SAVE CHANGES TO THE PROGRAM	F1 + ENTER	Program will be saved to default location.
SYSTEM RESET	RESETS THE MACHINE AND ALL AXIS ARE REVERTED TO THE ZERO POSITION	F1 + ▼ + ENTER	User is prompted with a warning message confirming that no operations should be in progress. Press ENTER to confirm, ESC to escape the command.
SHUT DOWN	SHUT DOWN THE MACHINE 	F1 + ▼▼ + ENTER Alternatively, press CTRL + Q together	Before turning off, a warning message is displayed to reset all axes to the zero position. The user will be prompted to save changes to the program if changes were made after the last save. Press Y to reset, N to continue without reset, ESC to escape the command.
SET MANUAL MPG		F1 + ▼▼▼ + ENTER	Allows user to manually operation program, step by step.

03.1.2 – F1 MODE: OPERATION MODES




To access the main menu bar, press F1 on the keyboard and move using arrows ◀ ▶ located on the keyboard. To exit, press ESC.

EDITING	Program creation and edit MODE	F1 + ▶ + ENTER
PRODUCTION	Production MODE	F1 + ▶ + ▼ + ENTER


The two operating modes encompass all methods of operation to produce springs and various components and display the various values and parameters used during a specific program. The first mode (EDITING) is more complex as it serves to design the movement sequence and fine-tune the program to produce the component. The second method (PRODUCTION) is used to set the production quantity.

The transition from one to the other is done by square brackets keys “[“ for EDIT MODE and “]” for PRODUCTION MODE. The bracket keys are located on the keyboard. The operator can also access operating mode via the main menu bar. Press F1 and then the ▶ arrow to highlight the MODE menu option. From there, the operator can choose either operating MODES.


03.1.3 – F1 FILE: OPERATIONS ON FILE



To access the main bar, press F1 on the keyboard and move using the arrow keys ◀ ▶ located on the keyboard. To exit, press ESC.

OPEN	<p>OPEN AN EXISTING PROGRAM</p> 	F1 + ▶▶ + ENTER	Select folder where file resides, then choose file name
NEW	CREATE A NEW FOLDER OR NEW FILE WITHIN A FOLDER	F1 + ▶▶ + ▼ + ENTER	It is essential to save and close all existing files before creating a few file.
SAVE	SAVE CURRENT PROGRAM	F1 + ▶▶ + ▼▼ + ENTER	
SAVE AS	SAVE CURRENT FILE WITH A FILENAME	F1 + ▶▶ + ▼▼▼ + ENTER	
CLOSE FILE	CLOSE CURRENT PROGRAM	F1 + ▶▶ + ▼▼▼▼ + ENTER	The current file should be saved before it is closed.
CLEAR DATA	CLEAR ALL DATA DISPLAYED IN THE PROGRAM	F1 + ▶▶ + ▼▼▼▼▼ + ENTER	

03.1.4 F1 - SYSTEM: MACHINE SETUP




To access the main menu, press F1 on the keyboard and move using the arrow keys ◀ ▶ located on the keyboard. To exit, press ESC.

SYSTEM SETTING	SETTING THE SYSTEM PARAMETERS FOR THE CURRENT PROGRAM THAT IS	F1 + ▶▶▶ + ENTER
----------------	---------------------------------------------------------------	------------------

	RUNNING, INCLUDING SERVO DRIVER SETTINGS	
SYSTEM I/O TEST	TEST VARIOUS INPUT AND OUTPUT POINTS THROUGH SYSTEM	F1 + ►►► + ▼ + ENTER
REGISTRATION	CURRENTLY NOT UTILIZED	F1 + ►►► + ▼▼ + ENTER

03.1.5 F1 - HELP



To access the menu bar, press F1 on the keyboard and move using the arrow keys ◀ ▶ located on the keyboard. To exit, press ESC.

ABOUT	INFORMATION ABOUT CURRENT MODEL	F1 + ►►►► + ENTER
USER'S MANUAL	CURRENTLY NOT UTILIZED	F1 + ►►►► + ▼ + ENTER

03.2 COMMANDS USED TO EXECUTE A PROGRAM



03.2.1 F3 – SAFE POSITION



To execute the command, press the F3 key on the keyboard. The command background changes color and the slides open up simultaneously to the default position, defined as the safe position. The safe position can also be defined as the zero position.

03.2.2 F4 – WIRE CUT



To execute the command, press the F4 key on the keyboard. The command background changes color and displays a confirmation window. The confirmation of this command will move the designated blade for the wire cut to the zero position, feed 20 mm of wire, quill rotates to the cutting position. The designated blade moves in for the cut and then returns to its original position. To use this function, the default blade used must be set with the F2 menu, to be discussed in a subsequent section.

03.2.3 F5 – RUN TO



This will execute the command according to the current operating mode. While in EDIT MODE, use the arrow ▼ ▲ keys to move to the user's desired program line, and then press F5 on your keyboard. The command background changes color and the program executes from the first line of code to the line of code immediately preceding the user's selection. In PRODUCTION MODE, pressing the F5 key will start production.

Important Note: Before executing the program by pressing F5, it is important to verify that the machine and its parts are in its proper place to allow for safe operations.

03.2.4 F6 – STOP

A rectangular button with a dark grey background and a brown border. The text "STOP [F6]" is displayed in a white, monospaced font.

This will execute the command according to the current operating mode. In EDIT MODE, pressing F6 will stop the program after the current line of code is executed. In PRODUCTION MODE, press F6 to stop the production of the program after execution of the last line of code.

03.2.5 F7 – RUN TOP

A rectangular button with a dark grey background and a brown border. The text "RUN TOP [F7]" is displayed in a white, monospaced font.

To execute the command, press the F7 key on the keyboard. The program will automatically move to the first line of code. This command is commonly used before using the F8 RUN LINE to execute the program step by step or to use MPG mode.

03.2.6 F8 – RUN LINE

A rectangular button with a dark grey background and a brown border. The text "RUN LINE [F8]" is displayed in a white, monospaced font. A mouse cursor is positioned over the text.

To execute the command, press the F8 key on your keyboard. The software executes the commands in the highlighted line of code only and moves the cursor to the next line of code.

03.2.7 F9 – RUN TO BREAK

A rectangular button with a dark grey background and a brown border. The text "RUN TO BRK [F9]" is displayed in a white, monospaced font.

To execute the command, press F9 on the keyboard. The command executes the program from the line where the pointer is located first row to the row prior to where the break point identified. To mark the break point on a line of code, move to that line of code and then press M on the keyboard. If the caps lock on the keyboard is activated, the M key will not mark the break point. If no break point is indicated within the program, a prompt will be shown when the user presses the F9 key.

03.2.8 PRODUCTION SPEED



In PRODUCTION MODE use the + and - buttons on the numeric pad or the O and P button on the keyboard to increase or decrease the speed of the machine.

REMEMBER: in EDIT MODE the + and – key on the keyboard determines the wire feed. Make sure you are using the correct keys in each operations mode.

03.3 MENU DISPLAY AREA



This area provides information during the normal operations of the program:

[+/-]: - The feed of wire that moves forward or backward by pressing the + and - in the EDIT MODE for each press of the button.

BLADE: - identify the active slide that will be controlled by the RPG

P-INDE): - the number of lines processed by the program

FILE: - folder and name of the program currently loaded.

03.4 STATUS BAR



Status Bar provides the following information:

[OS]: - displays the current operating mode and whether an axis reset is necessary.

[ERROR]: - displays active alarms.

[FILE]: - shows if the program has changed and whether saving is needed.

[POWER]: - shows the status of the servo drives and whether they are turned on or off.


[TIME]: - the current date and time

[MODE]: - displays the current mode of operations: EDIT or PRODUCTION

[PIN]: - displays the status of the input signal of the probes, used primarily for precision on rotations and angles.


03.5 SETTING AXIS BAR

03.5.1 EDIT MODE



This is the design area for a new program. The parameters entered are dependent on the machine and the tooling equipped. The values should be set prior to saving the sequence of the axis movements.


03.5.1.1 – F2 - AXIS ENABLE/DISABLE AND BLADE CUT DESIGNATION



To access the menu, press the F2 key and scroll arrows ◀ ▶ located on the keyboard. To exit, press the ESC key.

ENABLE/DISABLE AXISES	ENABLE / DISABLE EACH AXIS	F2 + ENTER	This allows you enable and disable different axes on the machine.
AUTOMATIC CUTTER	AUTOMATIC CUTTER	F2 + ▼ + ENTER	This option sets the position of the Quill depending on which slide is designated as the wire cutter.


03.5.1.2 – F2 DEFAULT BLADE SPEED



To access the menu, press the F2 key and scroll arrows ◀ ▶ located on the keyboard. To exit, press the ESC key.

BLADE SPEED	DEFAULT SPEED FOR EACH BLADE IN PROGRAM	F2 + ▶ + ENTER	Speed must be set before designing the program; otherwise each line will require a manual adjustment after the fact.
FAULT FEED LENGTH	DEFAULT FEED LENGTH	F2 + ▶ + ▼ + ENTER	Set the default feed length when the probe sensor cannot detect the wire.
SAFE POS RQ <->	SAFE POSITION FOR RETRACTING QUILL	F2 + ▶ + ▼ + ▼ + ENTER	Sets the safe position of the retracting quill. Typically is where the quill mount is flush with the face of the machine


03.5.1.3 – F2 SET [+/-] WIRE FEED LENGTH FOR KEYS + AND –



To access the menu, press the F2 key and scroll arrows ◀ ▶ located on the keyboard. To exit, press the ESC key.

20 – 50 – 100 – 350 mm	WIRE FORWARD/BACKWARD LENGTH FOR BUTTONS + AND -	F2 + ▶▶ + ENTER
---------------------------	-----------------------------------------------------	-----------------

03.5.1.4 – F2 CHANGE SPEED: SPEED ADJUSTMENT ON PROGRAM STEPS



To access the menu, press the F2 key and scroll arrows ◀ ▶ located on the keyboard. To exit, press the ESC key.

GROUP SPEED	CHANGE THE SPEED OF EACH LINE WITH SAME VALUE	F2 + ▶▶▶ + ENTER
FEED SPEED ONLY	CHANGE ONLY THE FEED SPEED OF EACH LINE	F2 + ▶▶▶ + ▼ + ENTER
BLADE SPEED ONLY	CHANGE ONLY THE BLADE SPEED OF EACH LINE	F2 + ▶▶▶ + ▼▼ + ENTER
RW SPEED	CHANGE ONLY THE ROTARY WIRE SPEED OF EACH LINE	F2 + ▶▶▶ + ▼▼▼ + ENTER
RQ SPEED	CHANGE ONLY THE ROTARY QUILL SPEED OF EACH LINE	F2 + ▶▶▶ + ▼▼▼▼ + ENTER

03.5.2 PRODUCTION MO



Settings in this operation mode serve to designate production quantities.

03.5.2.1 – F2 SETUP: PRODUCTION SETUP AND QUANTITY RESET



To access the menu, press the F2 key and scroll arrows ◀ ▶ located on the keyboard. To exit, press the ESC key.

SET PRODUCTION	SPECIFY PRODUCTION QUANTITY	F2 + ENTER
CLEAR COMPLETED	RESET QUANTITY OF COMPLETED PARTS	F2 + ▼ + ENTER
CLEAR PROBE ERROR	RESET ERROR WARNINGS BY PROBE	F2 + ▼▼ + ENTER

03.5.2.2 – F2 FEED ON / OFF: WIRE FEED




To access the menu, press the F2 key and scroll arrows ◀ ▶ located on the keyboard. To exit, press the ESC key.

FEED ON	WIRE FEED ENABLED	F2 + ▶ + ENTER
FEED OFF	WIRE FEED DISABLE	F2 + ▶ + ▼ + ENTER

03.6 SPECIAL KEYS

03.6.1 Z – Air Probe 1

The Z key on the keyboard controls the opening/closing of Air Probe 1 [Z] and alternates between a value of 0 and a value of 1.



03.6.2 X – Air Probe 2


The X key on the keyboard controls the opening/closing of Air Probe 2 [X] and alternates between a value of 0 and a value of 1.

03.6.3 C – Air Probe 3

The C key on the keyboard controls the opening/closing of Air Probe 3 [C] and alternates between a value of 0 and a value of 1.

03.6.4 B – RPG MODE


Press the B key to activate the axis motion control using the RPG. Pressing the R button displays this window:



The left panel displays the current position of all axes. By rotating the RPG, the active axis will move accordingly and its value will be updated on the left panel. The current axis in motion will be highlighted in yellow; everything else will be in grey. The current line of code being run will be highlighted in blue on the right panel. By using the ◀ ▶ keys is possible increase or decrease the movement sensibility of the RPG. The numeric keys 1 thru 9 can be used to adjust the operations speed of the program. The T key can be used to finish the current line of code automatically. This is typically used if the current line of code is lengthy.

03.6.5 USE ◀ ▶ TO INCREASE / REDUCE RPG SENSIBILITY

When the user is in manual RPG mode, use the ◀ and ▶ keys to adjust the sensibility of its movement. The available values are from 0.01 mm to 4 mm.



The present value of the RGB is indicated after “SPEED” from the illustration above.

03.6.6 S Key – WIRE FLAT POSITION


Press S on the keyboard. The mechanisms within the machine will be moved to a horizontal position, which can be set in the System Setting option. This setting is typically used before the start of a program.

03.6.7 D Key – WIRE CHANGE POSITION

Press D on the keyboard. The mechanisms within the machine will be moved to a vertical position, which can be set in the System Setting option. This is the optimal position to set new wires or to make adjustments to existing wire feeds. Additional controls are available from within

03.6.8 G Key – GO TO LINE

When you press the G key, a pop up window is displayed.



In this window you enter the line of code you would like to go to and press enter.

03.6.9]/[– PRODUCTION MODE / EDIT MODE

Press the “[“ or “]” to switch between modes of operation, production or editing.

03.6.10 P – WIRE FORWARD


Press P key to feed wire. The length of the feed depends on how it was set in the system within the F2 submenus as explained in section 03.5.1.3.

03.6.11 O – WIRE BACKWARD

Press the O key to retract the wire. The length the wire retracts depends on how it was set in the system within the F2 submenus as explained in section 03.5.1.3.

03.6.12 R – ROTARY TEST

Press the R key to activate manual RPG mode while in Rotary Test. The following screen will be displayed:



The left panel displays the current position of all axes. By rotating the RPG, the active axis will move accordingly and its value will be updated on the left panel. The current axis in motion will be highlighted in yellow; everything else will be in grey. The current line of code being run will be highlighted in blue on the right panel. By using the ◀ ▶ keys is possible increase or decrease the movement sensibility of the RPG. The numeric keys 1 thru 9 can be used to adjust the operations speed of the program. The T key can be used to finish the current line of code automatically. This is typically used if the current line of code is lengthy.

03.6.13 + / - TO INCREASE / REDUCE RUN SPEED

Use the + and – keys to adjust the speed of the program as indicated in section 03.2.8.