

## **Table of Contents**

- 01. DESCRIPTION OF OPERATION
- 02. LOCATION OF CONTROLS ON OPERATIONAL PANEL
- 03. MONITOR DISPLAY
  - 03.1 MAIN BAR OF EDIT MODE
    - 03.1.1 F1 MAIN: FUNCTION FOR BASIC USE
    - 03.1.2 F1 MODE: OPERATION MODES
    - 03.1.3 F1 FILE: FILE OPERATIONS
    - 03.1.4 F1 SYSTEM: MACHINE SETUP
    - 03.1.5 F1 HELP
  - 03.2 COMMAND BAR FOR EXECUTING PROGRAM
    - 03.2.1 F3 – SAFE POSITION
    - 03.2.2 F4 – WIRE CUT
    - 03.2.3 F5 – RUN TO
    - 03.2.4 F6 – STOP
    - 03.2.5 F7 – RUN TOP
    - 03.2.6 F8 – RUN LINE
    - 03.2.7 F9 – RUN TO BREAK
    - 03.2.8 PRODUCTION SPEED
  - 03.3 MENU DISPLAY AREA
  - 03.4 STATUS BAR
  - 03.5 SETTING AXIS BAR
    - 03.5.1 EDIT MODE
      - 03.5.1.1 F2 - AXIS ENABLE/DISABLE AND BLADE CUT DESIGNATION
      - 03.5.1.2 F2 DEFAULT BLADE SPEED
      - 03.5.1.3 F2 SET [+/-] WIRE FEED LENGTH FOR KEYS + AND –
      - 03.5.1.4 F2 CHANGE SPEED: SPEED ADJUSTMENT ON PROGRAM STEPS
    - 03.5.2 PRODUCTION MODE
      - 03.5.2.1 F2 SETUP: PRODUCTION SETTING AND QUANTITY RESET
      - 03.5.2.2 F2 FEED ON/OFF: WIRE FEED
      - 03.5.2.3 Lock Screen

## 03.6 SPECIAL KEYS

- 03.6.1 Z – Air Probe 1
- 03.6.2 X – Air Probe 2
- 03.6.3 C – Air Probe 3
- 03.6.4 B – RPG MODE
- 03.6.5 USE ◀ ▶ TO INCREASE / REDUCE RPG SENSIBILITY
- 03.6.6 S Key – WIRE FLAT POSITION
- 03.6.7 D Key– WIRE CHANGE POSITION
- 03.6.8 G Key– GO TO LINE
- 03.6.9 ] / [ – PRODUCTION / EDIT MODE
- 03.6.10 P – WIRE FORWARD
- 03.6.11 O – WIRE BACKWARD
- 03.6.12 R – ROTARY TEST
- 03.6.13 + / - INCREASE/REDUCE RUN SPEED

## 04. SWITCH ON THE MACHINE

- 04.1 TURN ON THE COMPUTER AND SERVO MOTORS
- 04.2 SWITCH ON AND RESET DECOILER
- 04.3 DECOILER: ROTATION DIRECTION AND SPEED CONTROL

## 05. MACHINE- SWITCH ON AND SWITCH OFF

- 05.1 MACHINE SWITCH ON
- 05.2 CALIBRATION AND ZERO POSITION OF AXIS
- 05.3 MANUAL MOVEMENT OF AXES
- 05.4 TURNING OFF SERVO DRIVES
- 05.5 EXIT PROGRAM AND SHUTDOWN SYSTEM

## 06. SYSTEM SETUP –GENERAL MACHINE SETUP

### 06.1 SYSTEM SETUP

- 06.1.1 A- BOUNDARY SETTING
- 06.1.2 TIMING SETTING
- 06.1.3 PLATFORM SETTING
  - 06.1.3.1 SELECT LANGUAGE
  - 06.1.3.2 PLATFORM ID
  - 06.1.3.3 PROBE PIN TYPE
  - 06.1.3.4 ENABLE/DISABLE AXIS, SPINNER, ROTATING QUILL, WIRE ROTATION
  - 06.1.3.5 HYDRAULIC CUTTER
  - 06.1.3.6 AIR PROBES
  - 06.1.3.7 INDUCTOR

- 06.1.3.8 RESET MODE OF WIRE ROTATION AND QUILL
- 06.1.3.9 CLOSE DOOR CONTROL
- 06.1.3.10 OIL LOW CHECK
- 06.1.3.11 WIRE EMPTY CHECK
- 06.1.3.12 24V BREAK CHECK
- 06.1.3.13 POWER CHECK
- 06.1.3.14 TEMPERATURE CHECK
- 06.1.3.15 HYDRAULIC CHECK
- 06.1.3.16 HEATER CHECK
- 06.1.3.17 AUTO SAVE

## 06.2 SYSTEM I/O TEST

## 06.3 REGISTRATION

# 07. ARCHIVE MANAGEMENT PROGRAMS

## 07.1 OPEN

## 07.2 NEW

## 07.3 SAVE

## 07.4 SAVE AS

## 07.5 CLOSE

## 07.6 CLEAR DATA

# 08. SETTINGS FOR THE PART PROGRAM

## 08.1 ENABLE/DISABLE AXES

## 08.2 AUTOMATIC CUTTER

## 08.3 SLIDE SPEED

## 08.3 BIS WIRE FEED FAULT

## 08.4 AJUSTMENT WIRE FORWARD /REVERS

## 08.5 SET DEFAULT WIRE FEED/DETRACT LENGTH

## 08.6 SPEED DEFAULTS

### 08.5.1 GROUP SPEED

### 08.6.2 FEED SPEED ONLY

### 08.6.3 BLADE SPEED ONLY

### 08.6.4 ROTATION WIRE SPEED

### 08.6.5 ROTARY QUILL SPEED

# 09. PROGRAMING

## 09.1 POSITIONS MEMORY

## 09.2 F3 – SAFE POSITION AND WIRE CUT

10. PROGRAM TESTING
  - 10.1 STEP BY STEP CODE EXECUTION
  - 10.2 BREAK POINTS
  - 10.3 SPEED REGULATION
  - 10.4 ROTATION TESTING
11. PROGRAM MODIFICATION
  - 11.1 DIRECT AXIS MODIFICATIONS
  - 11.2 SELECTIVE MODIFICATIONS
12. REPEAT A LINE OF CODE (LOOP)
13. USE OF PNEUMATIC CONTROLS, PROBE & TIMER
  - 13.1 PNEUMATICS CONTROLS
  - 13.2 MANUAL PNEUMATIC CONTROLS
  - 13.3 PROBE GRAPH SETUP
  - 13.4 TIMERS
14. USE OF THE COMMAND ROW
  - 14.1 LINE ADDITION
  - 14.2 LINE DELETION
15. SPECIAL FUNCTIONS AND COMMANDS
  - 15.1 SAFE POSITION
  - 15.3 AUTOMATIC CUTTER
  - 15.4 WIRE FEED
  - 15.5 WIRE ROTATION SPECIAL POSITIONS
  - 15.6 FEED ON / OFF
16. SERIAL NUMBER AND SOFTWARE VERSION
17. ALARMS AND TECHNICAL ISSUES
18. COMPUTER MAINTENANCE
19. DECOILER MANUAL
20. SERVO DRIVER MAINTENANCE (In Development)
21. MAIN ELECTRIC SCHEME (In Development)
22. AIR SIGNAL SCHEME (In Development)
23. PAUSE CIRCUIT (In Development)
24. POSITION ZERO SENSOR (In Development)

25. PAYOFF DIAGRAM (In Development)
26. SERVO DRIVER PARAMETERS (In Development)
27. SERVO DRIVER PROGRAMING(In Development)
28. COMPUTER BACKUP (In Development)
29. LIST OF TOOLS AND SPARE PARTS